

# Operation Instructions For Carton Shredder



Plug it in and switch on



Turn isolator on



Feed cardboard on insert area



Collect shredded cardboard

## Controls



Forward



Off



Reverse



Emergency stop

## Emergency Stop - Reverse & Reset



Emergency stop will stop machine. Release emergency stop. Hold reverse for 2 seconds. Switch forward then immediately reverse.

## Matting



Full Scrunch  
2 Springs attached



Semi Scrunch  
1 Spring attached



Flat  
0 Springs attached